

KingTone^{EST. 1999}

THE RISE

THE RISE GIVES YOU CLASSIC GERMANIUM TREBLE BOOSTER TONES WITH MODERN VERSATILITY. WITH ITS HIGHLY INTERACTIVE CONTROLS, YOU CAN DIAL IN A WIDE RANGE OF SOUNDS, FROM DEEP FUZZ TO SUPER BRIGHT, GLASSY CLEAN SOUNDS. THE TONE CONTROL ALLOWS YOU TO TAILOR THE SOUND EVEN FURTHER, MAKING THE RISE AN ESSENTIAL TOOL FOR ANY GUITAR PLAYER.

I/O JACKS
I/O JACKS AUTOMATICALLY DISCONNECT THE BATTERY WHEN THE PEDAL IS UNPLUGGED

DC 9V-DC
POWER THE PEDAL FROM 9 BATTERY OR 9V DC

DRIVE
WIDE RANGE DRIVE CONTROL GOES FROM COMPLETELY CLEAN TO FUZZ STYLE TONES

VOLUME
HIGH OUTPUT VOLUME CONTROL CAN EASILY OVERDRIVE MOST AMPS

GLASS
THIS CONTROL LETS YOU ADJUST YOUR TONE FROM FAT FUZZ TONES TO GLASSY CLEAN AND EVERYTHING IN BETWEEN

DIP SWITCHES
SWITCH BETWEEN GE OR SI TRANSISTORS, CONTROL GLASS AMOUNT WITH EDGE/GLASS CONTROL AND LED BRIGHTNESS


FOOT SWITCH
TRUE BYPASS FOOT-SWITCH QUIET SWITCHING

TONE
POWERFUL TONE CONTROL ALLOWS FOR CUT AND BOOST OF MID TO HIGH FREQUENCIES

TOGGLE SWITCH
THE TOGGLE SWITCH LETS YOU GO FROM VINTAGE SPEC TREBLE BOOSTER TONES TO FULL ON FUZZ



EXAMPLE SETTINGS



- GERMANIUM TRANSISTOR
- GLASS ON
- LED HIGH



- SILICON TRANSISTOR
- EDGE ON
- LED LOW

GE/SI SI GIVES YOU HIGH GAIN, BRIGHT TONE, BOOST AND FUZZ. GE GIVES YOU WARM, GLASSY, LOW GAIN VINTAGE TONES

EDGE/GLASS GLASS GIVES YOU A BRIGHT HIGH END, EDGE GIVES YOU A PUNCHY EGY HIGH END

LED FOR OUTDOOR SHOWS OR BRIGHT ENVIRONMENTS SET TO HIGH, ON DARK STAGES SET TO LOW

PLEASE NOTE IF NO TRANSISTOR IS SELECTED WITH THE DIP SWITCH, THERE WILL BE NO SOUND OUTPUTTED