

Vintage Fuzz

VOLUME CONTROL

Volume Control. Provides a smooth sweep from subtle output to a powerful signal strong enough to push your amp into overdrive. Perfect for matching levels or adding extra punch.

BIAS CONTROL

Bias Control
Shapes the character and response of the fuzz circuit. Lower bias settings deliver a sputtery, gated "Bender-style" fuzz, while higher settings smooth things out into rich, overdriven tones. This is the most powerful tone-shaping tool on the Vintage Fuzz, subtle tweaks can completely transform your sound.

DIP SWITCHES

Tweak your tone under the hood. One switch enhances bass response for a fuller low end, while the other lets you choose between vintage output levels and a stronger, more modern high-output setting.

DC POWER JACK

Power the Vintage Fuzz from standard center negative DC power or internal battery. No need for adapters or center positive supplies.

FUZZ CONTROL



The Fuzz control
Sets the intensity of the fuzz, from a soft, smoky growl to full-on saturated chaos. Dial in just the right amount of filth for your tone.

TRANSISTOR SELECT


Transistor Select. Choose between vintage Germanium and classic Silicon transistors, or blend both for unique textures. Germanium delivers a warm, smooth, overdriven character, while Silicon brings a tighter, grittier, and more aggressive fuzz. Shape your sound from buttery sustain to snarling chaos.

TRUE BYPASS


Ensures your clean signal passes through untouched when the pedal is off. No tone suck, no coloration just your pure, unaffected sound exactly as it should be.




SUPER GLASSY CLEAN




BENDER GATED




WARM DRIVE



SRV - 1990



VIOLIN



HENDRIX